

FIG. 1




FIG. 2




FIG. 3

Title: IMAGE FORMING APPARATUS
AND METHOD OF CONTROLLING
THE APPARATUS

Inventor(s): Fumiharu NAKAYAMA
Serial No. 09/955,307




FIG. 4

Title: IMAGE FORMING APPARATUS
AND METHOD OF CONTROLLING
THE APPARATUS

Inventor(s): Fumiharu NAKAYAMA
Serial No. 09/955,307




FIG. 5

Initial screen

Do you make pre-registration ?

☒ YES

☐ NO

OK

FIG. 6

Select screen for copy mode

☒ Copy mode A

☐ Copy mode B

Next page

Back OK

FIG. 7

Setting screen for input/output screen

Specify size and direction of original document

☒ A4 Longitudinal ☐ A4 Lateral ☐ B5 Longitudinal ☐ B5 Lateral

Specify size and direction of paper

☒ A4 Longitudinal ☐ A4 Lateral ☐ B5 Longitudinal ☐ B5 Lateral

Specify number of sheets of original document

16

Back OK

FIG. 8




FIG. 9




FIG. 10

Title: IMAGE FORMING APPARATUS
AND METHOD OF CONTROLLING
THE APPARATUS

Inventor(s): Fumiharu NAKAYAMA
Serial No. 09/955,307





FIG. 11

Title: IMAGE FORMING APPARATUS
AND METHOD OF CONTROLLING
THE APPARATUS

Inventor(s): Fumiharu NAKAYAMA
Serial No. 09/955,307



Menu screen

Basic copy

Pre-registration mode

XX copy

YY copy


Input reservation number.

1 1

Set original document and turn on copy key.

The interface shows a menu screen with five options: 'Menu screen', 'Basic copy', 'Pre-registration mode', 'XX copy', and 'YY copy'. The 'Pre-registration mode' option is selected, leading to a screen where the user is prompted to 'Input reservation number.' There are two numeric input fields, each containing the number '1'. Below these fields, the instruction 'Set original document and turn on copy key.' is displayed.

FIG. 12



Re-input guide screen

Cancel

Pre-registration mode

Please input correct reservation number.

1 1

Set original document and turn on copy key.

The interface shows a 'Re-input guide screen' with a 'Cancel' button in the top right corner. The 'Pre-registration mode' option is selected. The screen prompts the user to 'Please input correct reservation number.' There are two numeric input fields, each containing the number '1'. Below these fields, the instruction 'Set original document and turn on copy key.' is displayed.

FIG. 13